



ELEVATION

INSTALLATION PROCEDURES:

1. THE CONTRACTOR SHALL TEMPORARILY PLUG LINE AT UPSTREAM MANHOLE UNDER DISTRICT SUPERVISION. THE CONTRACTOR IS RESPONSIBLE TO PROVIDE BY-PASS SEWAGE PUMPING AS REQUIRED.
2. EXPOSE AND REMOVE EXISTING PIPE.
3. PLACE EXISTING PIPE THROUGH NEW MANHOLE BASE SECTION WITH PRE-INSTALLED KOR-N-SEAL BOOTS. IF CUT PIPE SECTION CONTAINS A PIPE BELL, REPLACE PIPE WITH A NEW STRAIGHT SECTION OF PIPE, OR AS DIRECTED BY THE DISTRICT.
4. SET MANHOLE AND PIPE IN PLACE TO PROPER ALIGNMENT AND GRADE.
5. RECONNECT PIPE WITH COUPLINGS (ROMAC, MJ SLEEVE, OR PVC SLIP COUPLING).
6. CHANNEL MANHOLE PER DISTRICT STANDARDS.
7. REMOVE PIPE INSIDE MANHOLE.



SPECIAL MANHOLE CUT-IN INSTALLATION

REVISION DATE APRIL 12, 2021	SCALE NTS	DISTRICT APPROVAL <i>Gregory G. Hill, P.E.</i>	DATE APPROVED APRIL 18, 2023
FILE NAME S-1.DWG		DWG. NO.	S-1